




Indirect Fired, Ultra Capacity Side-By-Side Packaged Heating Equipment Table of Contents

	<u>Model</u>	<u>Description</u>	<u>Page No.</u>
OUTDOOR EQUIPMENT	RPDBL	Ultra Capacity, 80% Efficient, Outdoor, Power-Vented, Gas-Fired Packaged Heating Unit	
		Description / Standard and Optional Features	2
		Technical / Dimensional Data	3
		Gas Connection, Accessory Weights and Filter Information	6
INDOOR EQUIPMENT	SSCDBL	Ultra Capacity, 80% Efficient, Indoor, Separated Combustion, Gas-Fired Packaged Heating Unit	
		Description / Standard and Optional Features	4
		Technical / Dimensional Data	5
		Gas Connection, Accessory Weights and Filter Information	6
BLOWER DATA		Pressure Drop Chart	7
		RPM/BHP Table	8-9
OPTIONS AND GENERAL		Pilot and Gas Controls	10-11
		Special Manifolds	12
		Air Control Systems	12-13
		Discharge Air Configurations	14
		Installation Notes	14-15
		Sizing Gas Supply Lines	16
		Overview of Separated Combustion Systems	16-18
		Remote Consoles and Thermostats	19-21
		Full Load Amp Tables	22-23
	Sample Specifications	24-25	
	Warranty	26	

NOTE: Reznor Models RPDBL and SSCDBL are Ultra Capacity - Side-By-Side units. Each packaged unit consists of two Reznor Model RPBL or SSCBL packaged systems constructed Side-by-Side. Following is a graphic depiction of how these units are arranged.



IMPORTANT: This guide is intended to provide specifications and technical information only. This guide is not intended to be an instruction manual. When installing heating and ventilating equipment, you must check and conform to all local and national building codes. Improper installation of heating equipment could be dangerous. Consult manufacturer's installation manual for instructions and important warnings.

All specifications subject to change without notice.

In keeping with our policy of continuous product improvement, we reserve the right to alter, at any time, the design, construction, dimensions, weights, etc., of equipment information shown here.