

**INDOOR, SUSPENDED,  
STEAM OR HOT WATER  
HYDRONIC UNIT HEATER  
FOR VERTICAL OR HORIZONTAL  
CONFIGURATION**

**REZNOR**

*Thomas & Betts*



**TABLE OF CONTENTS**

Unit Description ..... 2

Standard Features ..... 3

Factory Installed Options ..... 3

Field Installed Options ..... 3

Technical Data ..... 3

Unit Dimensions ..... 3

Engineering Data - Hot Water Capacities, Calculations and Correction Factors ..... 4

Heat Exchanger Resistance, Water Pressure Drop Chart ..... 5

Engineering Data - Terms, Abbreviations and Formulas ..... 7

Engineering Data - Steam Capacities, Calculations and Correction Factors ..... 8

Effective Heat Cover and Air Throw ..... 10

Recommended Installation Details for Piping Connections ..... 11

Optional Equipment, Accessories - Description and Dimensions

    Optional Overhead Door Diffuser ..... 12

    Suspension Plate for Ceiling Installation ..... 13

    Optional Vertical Louvers ..... 13

    Optional Air Flow Induction Optimizer Dimensions ..... 14

    Optional Air Flow Induction Optimizer Description ..... 14

General Layout and Installation Suggestions ..... 16

**IMPORTANT:** This guide is intended to provide specifications and technical information only.

This guide is NOT intended to be an instruction manual. When installing heating and ventilating equipment, you must check and conform to all local and national building codes. Improper installation of heating and ventilating equipment could be dangerous. Consult manufacturer's installation manual for instruction and important warnings.

In keeping with our policy of continuous product improvement, we reserve the right to alter, at any time, the design, construction, dimensions, weights, etc., of equipment information shown here.